



5704-888

INSTALLATION INSTRUCTIONS

C-10 Pick Up Front Anti-Swaybar Adapter Kit

NOTE: PLEASE READ THE INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION. IF YOU DO NOT FEEL COMFORTABLE WITH THE INSTALLATION PROCEDURE, PLEASE REFER THE INSTALLATION TO A QUALIFIED MECHANIC.

CAUTION: Do not work under a vehicle being held up by a jack only. Place jack stands securely under the vehicle in the manufacturer's specified locations, unless instructed as to a different location.

1. Park the vehicle on a smooth level asphalt or concrete surface and set the parking brake firmly. Place a block in front of and behind the rear wheels. Jack up the front of the vehicle and place jack stands securely under the frame in the manufacturer's specified locations, check for vehicle stability and remove the front wheels.
2. Position short leg of main support bracket towards front of truck and fasten to existing holes in frame rails (Directly in front of idler arm and pitman arm).
3. Fasten main support bracket to frame rails using hardware supplied in kit. Torque hardware to 18 ft. lbs.
4. Go over the entire installation procedure and make sure all the bolts are properly torqued.

PARTS LIST

2	-	5704-001	Main Support Bracket
4	-	112094	3/8"-16 x 1 1/4" Hex Head Cap Screw
4	-	110255	3/8"-16 Nylock Nut
8	-	112518	3/8" USS Washer
1	-	5704-888	Installation Instructions