

## INSTALLATION INSTRUCTIONS

### SUBJECT: Heater Core Replacement Hose and Fitting for 2003-2024 RAM

FITMENT:2003-2024 5.9L and 6.7L Cummins Equipped Dodge Ram 2500/3500 Pickup TrucksKIT P/N:FPE-CUMM-HCL-0324

EST INSTALL TIME: 1 Hour

**TOOLS REQUIRED:** Pliers, 1/4" hex drive or socket, 7/8" deep well socket or wrench

#### **KIT CONTENTS:**

Item #	Description	QTY
1	Heater core hose	1
2	Heater core hose riser adapter	1
3	Hose clamp	2
4	Thread sealant	1



#### WARNINGS:

- Use of this product may void or nullify the vehicle's factory warranty.
- User assumes sole responsibility for the safe & proper use of the vehicle at all times.
- The purchaser and end user releases, indemnifies, discharges, and holds harmless Fleece Performance Engineering, Inc. from any and all claims, damages, causes of action, injuries, or expenses resulting from or relating to the use or installation of this product that is in violation of the terms and conditions on this page, the product disclaimer, and/or the product installation instructions. Fleece Performance Engineering, Inc. will not be liable for any direct, indirect, consequential, exemplary, punitive, statutory, or incidental damages or fines cause by the use or installation of this product.

FPE-2024-123 June, 2024 Page 1 of 4

#### **PROCEDURE:**

**STEP 1:** Disconnect both batteries and drain approximately 1 gallon of coolant from the coolant system.

**STEP 2:** Locate the upper heater core supply hose in the engine bay located on the (left) passenger side of the engine valve cover. Loosen and remove the hose clamp from the upper heater core hose at the firewall heater core connection.



**STEP 3:** Disconnect the upper heater core hose from the quick disconnect fitting on the passenger side of the cylinder head by compressing the hose retainers and lifting up on the connection. If necessary, use a flat head screwdriver to pry the hose adapter from the fitting. Remove the upper heater core hose from the engine bay.

**STEP 4:** Using a 7/8" deep well socket, loosen and remove the OE adapter fitting from the cylinder head.



#### QUICK REFERENCE

The OE quick disconnect fitting and the Fleece Performance riser fitting both contain a flow control orifice to manage overall coolant flow to the heater core.



**TOP VIEW** 



**STEP 5:** Apply thread sealant in a single bead around the lowest thread of the new heater core hose riser fitting.

**STEP 6:** Using a 7/8" deep well socket, install the new Fleece Performance riser fitting into the cylinder head port where the OE fitting was removed.

**STEP 7:** Install the new Fleece Performance heater core supply hose. Connect it to the upper heater core port at the firewall and the new riser fitting installed on the cylinder head. Use the supplied hose clamps to secure both ends of the hose and tighten them with a 1/4" socket or flat head screwdriver.









# **INSTALLATION INSTRUCTIONS**

**STEP 8:** Refill the coolant system and reconnect the battery terminals.

**STEP 9:** Start the vehicle and verify that no leaks are present.

